

HANG FIX

Installationsanleitung Bohrhaken

MADE IN ITALY



Hang Fix Ø8 - punta Ø8
Hang Fix Ø8 - drilling hole Ø8
Hang Fix Ø8 - punta Ø8
Hang Fix Ø8 - pointe Ø8

Hang Fix Ø10 - punta Ø10
Hang Fix Ø10 - drilling hole Ø10
Hang Fix Ø10 - punta Ø10
Hang Fix Ø10 - pointe Ø10

Hang Fix Ø12 - punta Ø12
Hang Fix Ø12 - drilling hole Ø12
Hang Fix Ø12 - punta Ø12
Hang Fix Ø12 - pointe Ø12

